


Pokini Tab K10 & K10B



2-Bay Battery Charger



Quick Start Guide



English

Overview



* The 2-Bay Battery Charger only supports the following AC adapter:
K10(B) series, 19VDC (3.43A)

Charging



| | |
|--|-------------------|
| | Charge: ~ 20% |
| | Charge: ~ 40% |
| | Charge: ~ 60% |
| | Charge: ~ 80% |
| | Charge: ~ 100% |
| | Full charge |

Support

You have any technical questions?

If you have problems or questions, please contact us by e-mail:

support@pokini.de

V1.2 / 10-2022

EXTRA Computer GmbH
Brühlstr. 12
89537 Giengen-Sachsenhausen
Deutschland / Germany

all rights reserved

www.pokini.de